




Starting XC2 on Windows Vista Operating Systems

Technical Note

October 31, 2008

In order for XC2 to run on PC's running Microsoft's Windows Vista, You must first change the compatibility settings.

- Right Click on the XC2 Icon
- Next Click on "Properties"



- Click the “Compatibility” Tab
- Check the box “Run this program in compatibility mode for”
- Windows XP
- Click “Apply”, then Click “OK”
- XC2 will now run in Windows Vista

